


Orchestra Stand Instruction Manual

Parts

The orchestral stand comes in two main parts:-



Assembly



1. Slacken off the leg locking nut (Fig 1) and pull legs into a spread position with a downward movement.
2. Ensure that the legs are fully extended as wide possible, this will ensure that the stand will not topple when used at full height or in windy conditions.
3. Retighten the leg locking nut, but do not over tighten, just tighten until the legs do not move. There is no danger if this nut has not been tightened enough.
4. Slacken off the tube locking nut (Fig 2) and extended the inner tube to the desired height. Retighten the locking nut. Do not over tighten the nut, tighten enough to stop the tube sliding down.
5. Slacken off the main desk locking nut (Fig3) and connect desk to leg tube. Retighten the desk locking nut until the desk does not rotate, do not over tighten.
6. The tilt of the desk can be adjusted by slackening the two desk tiling nuts (Fig 4). Once at the required angle retighten the nuts, do not over tighten as damaged will occur, tighten until the desk no longer moves.

Disassemble

1. Disassemble in the reverse order described above.
2. Ensure that after slackening nuts that you retighten so that they are not lost in transit.
3. If you have an optional bag then the stand can be stored and transported securely.